


## Mounting recommendation MONTAWALL®



## Cassette *MONTAWALL*®

Sealing tape
Variante 1: Applied by Montana
Variante 2: Applied on site
GYSO sealing tape G-410,
Width 19 mm, Thickness 3 mm

Place the metal nail least 30 mm next to the sealing tape.
Nail HILTI X-ENP 19 L15
Drilling screw SFS St vz SD14-H15-5, 5x34
Drilling screw SFS Drill tip St A2
drill point hardened SX14-5, 5x40

Place this nail in the lowest rib with base plate or use a self-drilling screw.

Screwing in the web with self-drilling screw (recommendation: every 1'000 mm)

For an additional vapour-tight construction, seal in the joint between the cassettes with sealing tape as an additional measure.

GYSO-Tape V-712,
Thickness 0,8 mm, Width 50 mm

See also MONTANA help sheet, Application instructions sealing tape" as well as installation instructions and data sheets of the companies mentioned.

